

# HCB WIRING GUIDE

EP.S3150

EP.N5150

EP.S3200

EP.N5200

EP.S3400

EP.N5400

Version: 1.18

Last Updated: 18-07-2018

ENTRYPASS TECHNICAL – WIRING GUIDE

Copyright © Entrypass Corporation



## Notes:

N5150, N5200 and N5400 are network enabled controllers  
S3150, S3200 and S3400 are serial enabled controllers

N5150 and S3150 have 4 inputs and 2 Outputs (2 Relays – Support 2 Doors, 2 Readers)  
N5200 and S3200 have 8 inputs and 4 outputs (4 Relays - Support 2 Doors, 2 Readers). N5400  
and S3400 have 8 inputs and 4 outputs (4 Relays – Support 4 Doors, 4 Readers)

N5200, S3200, N5400 and S3400 support unlimited access level  
N5150 and S3150 not support unlimited access level

S3150, S3200, S3400, N5150, N5200 and N5400 support HID (AGK00, 09, 10, 11, 14, 19, 20),  
Wiegand Multi-Bit, Keyed Card + Pin

N5150, N5200 and N5400 support AES Encryption

S3200, S3400, N5200, N5400 support event trigger

See <http://www.entrypass.net/> for updates, revisions, and download the latest installation  
manual

Platform1 version 3 support 6 and 10 digits format  
For existing site, P1 will detect its card database to determine 6 or 10 digits; For new site, user  
can change the digits as long as the card database is empty

Please refer to separate EntryPass Platform1 User Manual for detail operation help. The Official  
EntryPass Platform1 User Manual can be downloaded from our website under “Download”  
section or inside the Platform1 Server setup CD



# BEFORE YOU BEGIN

## Technical Support

If you cannot find the answer to your question in this manual or in the Help files, we recommend you contact your system installer. Your installer is familiar with your system configuration and should be able to answer any of your questions.

Should you need additional information, please call our Technical Support Help desk, Monday to Friday 9:00 AM to 6:00 PM (GMT +8:00)

### Method Details

Phone + 60 (3) - 8068 1929

Fax + 60 (3) - 8068 1922

Internet [www.entrypass.net](http://www.entrypass.net)

Email [support@entrypass.net](mailto:support@entrypass.net)



# Considerations Prior to Installation

## Preparing Your EntryPass Controllers

EntryPass controller contains numerous delicate electronic circuits and components which can become damaged as a result of electrostatic discharge (ESD). Thus, prior to installation, please follow the instruction below:

- Observe precautions while handling the circuit board assembly by using proper grounding straps and handling precautions at all
- Visually ensure no onboard parts is broken, damage or contains burn mark
- Do not turn on the power supply until you completed all wiring and external add on devices installations



### **CAUTION**


Battery may explode if mistreated. Do not recharge, disassemble or dispose of in fire. To prevent a risk of explosion do not pry the battery out with a metal or conductive tool.

## Instances of Non-Warranty

- Damage due to natural disaster, accident or human cause.
- Damage as a result of violating the conditions recommended in the user manual
- Damage due to improper installation
- Damage due to use of uncertified components
- Damage due to use exceeding the permitted parameters





# Components Description



# Legend Description

## Lower Connector




I1D0	- Reader 1 Data 0 Input	O1D0	- Reader 2 Data 0 Input
I1D1	- Reader 1 Data 1 Input	O1D1	- Reader 2 Data 1 Input
LED1	- Reader 1 LED	LED2	- Reader 2 LED
BUZ1	- Reader 1 Buzzer	BUZ2	- Reader 2 Buzzer
IN1	- Input 1 (Default: Door Sensor)	IN3	- Input 3
IN2	- Input 2 (Default: Exit Push Button)	IN4	- Input 4
GND	- Inputs Ground	GND	- Inputs Ground
NC1	- Relay 1 Normally Close Connection	C3-	- RS485 COM3 (-) Connection
COM1	- Relay 1 Common Input	C3+	- RS485 COM3 (+) Connection
NO1	- Relay 1 Normally Open Connection	C2-	- RS485 COM2 (-) Connection
NC2	- Relay 2 Normally Close Connection	C2+	- RS485 COM2 (+) Connection
COM2	- Relay 2 Common Input	C1-	- RS485 COM1 (-) Connection
NO2	- Relay 2 Normally Open Connection	C1+	- RS485 COM1 (+) Connection
VR1+	- Supply Voltage Positive Connection		
(12V/5V)			
GND	- Supply Voltage Ground Connection		

For VR1+ to supply 12V, please make sure JP6 is at 1-2 pins  
 For VR1+ to supply 5V, please make sure JP6 is at 2-3 pins



# Legend Description




## Upper Connector - Only for EP.S3200, EP.S3400, EP.N5200, EP.N5400

I2D0	- Reader 3 Data 0 Input	VR2+	- Supply Voltage Positive Connection
I2D1	- Reader 3 Data 1 Input	(12V/5V)	
LED3	- Reader 3 LED	GND	- Supply Voltage Ground Connection
BUZ3	- Reader 3 Buzzer	O2D0	- Reader 4 Data 0 Input
IN5	- Input 5	O2D1	- Reader 4 Data 1 Input
IN6	- Input 6	LED4	- Reader 4 LED
NC3	- Relay 3 Normally Close Connection	BUZ4	- Reader 4 Buzzer
COM3	- Relay 3 Common Input	IN7	- Input 7
NO3	- Relay 3 Normally Open Connection	IN8	- Input 8
NC4	- Relay 4 Normally Close Connection	IN9	- Reserved
COM4	- Relay 4 Common Input	GND	- Inputs Ground
NO4	- Relay 4 Normally Open Connection		

For VR2+ to supply 12V, please make sure JP7 is at 1-2 pins  
 For VR2+ to supply 5V, please make sure JP7 is at 2-3 pins



# Legend Description



## Power Supply Connector


- |          |                                |
|----------|--------------------------------|
| +12V     | - Power Supply Positive 12V DC |
| -12V/GND | - Power Supply Ground          |
| ETH      | - Power Supply Earthing        |
| ACC      | - AC Fail Monitoring           |
| BAT/BS   | - Backup Battery Monitoring    |

BAT/BS (Backup Battery Monitoring) point will monitor the backup battery voltage which will supply power to the board when AC power is cut off  
The minimum voltage for cutoff while using backup battery is 10.8V





# Power Supply Unit Specification




## Power Supply Unit Specification:

- Switching Power Supply
- 12V DC
- 3 Amp (Minimum)




# Connecting the Lock (NC), Breakglass and Keyswitch



Diode(1N4002) must be installed at the locking devices in order to protect against back EMF. It is advisable to connect EM lock COM to +12V of PSU (Power Supply Unit)




# Connecting the Striker Lock or Drop Bolt (NO)



Diode(1N4002) must be installed at the locking devices in order to protect against back EMF




# Connecting the Lock (NC), Breakglass and Keyswitch (2 Doors Mode Only)



Diode(1N4002) must be installed at the locking devices in order to protect against back EMF




# Connecting the Lock (NO), Breakglass and Keyswitch (2 Doors Mode Only)



Diode(1N4002) must be installed at the locking devices in order to protect against back EMF




# Connecting the Lock (NC), Breakglass and Keyswitch (4 Doors Mode Only)



Diode(1N4002) must be installed at the locking devices in order to protect against back EMF  
 NC1 and NC2 connection for 4 Doors Mode, please refer to 2 Doors Mode NC connection  
 4 Doors Mode only applicable for N5400 and S3400




# Connecting the Lock (NO), Breakglass and Keyswitch (4 Doors Mode Only)



Diode(1N4002) must be installed at the locking devices in order to protect against back EMF  
NO1 and NO2 connection for 4 Doors Mode, please refer to 2 Doors Mode NO connection  
4 Doors Mode only applicable for N5400 and S3400




# Connecting the Door Sensor and Push Button






# Connecting the Door Sensor and Push Button (2 Doors Mode)




# Connecting the Door Sensor and Push Button (4 Doors Mode)



IN1,2,3,4 Connections for 4 Doors Mode please refer to 2 Doors Mode IN1,2,3,4 connections 4 Doors Mode only applicable for N5400 and S3400



# Connecting the Reader – 3<sup>rd</sup> Party Reader




Reader 3 and Reader 4 only applicable for N5400 and S3400



# Connecting the Reader – Suprema V2 Devices

Support the following Suprema V2 devices:


- 1) BioStation A2
- 2) BioStation 2
- 3) BioStation L2
- 4) BioEntry W2
- 5) BioEntry P2
- 6) BioLite N2



Each of the Suprema device require power of 12VDC, 500mA ~ 1A depend on the model




# Connecting the Reader – Entrypass BR100 Devices



Each of the BR100 device require 12VDC, 1A power supply



# Connecting to Another Controller for Cross-Board Interlock




Maximum 2 controllers can be connected each others for cross-board interlock purpose  
An interlock input and interlock relay need to be assigned using Platform1 Server for cross-board interlock on each controller

Please configure the interlock input as 'Open Trigger' in Platform1 Server, if interlock input is connected with NC relay output. Advisable to use analog input for detecting line open condition

The cabling distance for cross-board interlock connection can up to 100 meter




# Connecting to the PC via RS485 Mode



Serial connection (RS485) only applicable for maximum 16 sets S3150/S3200/S3400  
The serial address format in Platform1 is 255.255.255.X where X is unit address



# Connecting to the PC via RS232 Mode



Serial connection (RS232) only applicable for a single S3150/S3200/S3400  
The serial address format in Platform1 is 255.255.255.1





# Connecting to the PC via Serial: Dip Switch Addressing Table

	Switch 1 (1)	Switch 2 (2)	Switch 3 (4)	Switch 4 (8)	Switch 5 (16)
Address 01	ON	OFF	OFF	OFF	OFF
Address 02	OFF	ON	OFF	OFF	OFF
Address 03	ON	ON	OFF	OFF	OFF
Address 04	OFF	OFF	ON	OFF	OFF
Address 05	ON	OFF	ON	OFF	OFF
Address 06	OFF	ON	ON	OFF	OFF
Address 07	ON	ON	ON	OFF	OFF
Address 08	OFF	OFF	OFF	ON	OFF
Address 09	ON	OFF	OFF	ON	OFF
Address 10	OFF	ON	OFF	ON	OFF
Address 11	ON	ON	OFF	ON	OFF
Address 12	OFF	OFF	ON	ON	OFF
Address 13	ON	OFF	ON	ON	OFF
Address 14	OFF	ON	ON	ON	OFF
Address 15	ON	ON	ON	ON	OFF
Address 16	OFF	OFF	OFF	OFF	ON


Each switch is represent by an address, the sum of the switch address will be the controller address

The number in ( ) is the address of each individual switch of the dip switch

Example: To obtain Address 11,  $1 + 2 + 8 = 11$ , So just switch on switch 1, 2, 4




# Connecting to the PC via Network




Network connection only applicable for N5150, N5200 and N5400  
Factory default IP address for network controller is 192.168.1.100



# Connecting to Power Supply Unit



# Performing Cold Start




Steps of performing cold start:

1. Please ensure that the jumper is inserted on JP1 1-2
2. Press and Hold COLD switch
3. Press RESET Switch and Release RESET switch
4. Release COLD switches when a long beeping sound heard

Advisable to perform cold start for the first time you turn on the power  
The buzzer will only beep if jumper is placed on (JP2) 1-2



# Performing Factory Default



Steps of performing Factory Default:


1. Please ensure that the jumper is inserted on JP1 7-8
2. Press and Hold COLD switch
3. Press RESET Switch and Release RESET switch
4. Release COLD switches when a long beeping sound heard

Factory Default will change the IP Address back to 192.168.1.100, Server IP to 192.168.1.254 and Port to 2020

For the network controller support AES Encryption feature, factory default will disable the AES feature



# Performing AES Hard Reset



Steps of performing AES Hard Reset:



1. Please ensure that the jumper is inserted on JP1 3-4
2. Press RESET Switch and Release RESET switch

AES setting in the controller will be reset

If the controller is connected with AES enabled Platform1, Platform1 will sync and update AES setting with the controller




# Input Point Connection




## Digital Input Connection

By manufacturer default setting, IN1 is configured as Door Sensor and IN2 is configured as Push Button.



## Analog/Supervised Input Connection


A resistor of 3.6kΩ is required when user connect the device to the input connection.



The Inputs are configurable to digital (default) or analog using Platform1  
 A resistor of 3600 ohm is required when using analog input  
 This system is not support NO Analog device due to the architecture



# Complete Overview (In and Out Door Mode)




Serial Controller – S3150, S3200, S3400  
 Network Controller – N5150, N5200, N5400

Platform1 Profile: In and Out Readers






# Complete Overview (2 Doors Mode)




# Complete Overview (2 x In and Out Doors Mode)



Platform1 Profile: 2 x In and Out Doors




# Complete Overview (4 Doors Mode)




Platform1 Profile: 4 Doors




# Complete Overview (In and Out Barriers)



# Complete Overview (2 x In and Out Barriers)



# Complete Overview (In and Out Turnstile Mode)




Serial Controller – S3150, S3200, S3400  
 Network Controller – N5150, N5200, N5400

Platform1 Profile: In and Out Turnstile



# Complete Overview (2 Turnstiles Mode)




Serial Controller – S3150, S3200, S3400  
 Network Controller – N5150, N5200, N5400

Platform1 Profile: 2 Turnstile Mode



# Complete Overview (2 x In and Out Turnstiles Mode)




Platform1 Profile: 2 x In and Out Turnstiles





# Complete Overview (4 Turnstiles Mode)



Serial Controller – S3400  
Network Controller – N5400

Platform1 Profile: 4 Turnstiles



# Cabling Information

Communication	Data Signal	Max Distance	Description
PC to PCC	RS232	10m (30 ft)	22 AWG, 2 Pairs, Shielded
PCC to Serial Controller	RS485	1000m (3000 ft)	22 AWG, 2 Pairs, Shielded & Twisted Pair
Network Controller or Reader to PC or Network Switch	Network	100m (300 ft)	24 AWG, 4 Pairs (Cat 5e)
Controller to Reader	Wiegand	30m (100 ft)	22 AWG, 2 Pairs, Shielded & Twisted Pair
Controller to Electro-Magnetic Lock	Power	30m (100 ft)	18 AWG, 1 Pair
Controller to Push Button	Contact	30m (100 ft)	22 AWG, 1 Pair
Controller to Door Sensor	Contact	30m (100 ft)	22 AWG, 1 Pair
Controller to Controller for Cross-Board Interlock	Contact	100m (300 ft)	22 AWG, 1 Pair

Serial Controller – S3150, S3200, S3400  
 Network Controller – N5150, N5200, N5400

