

EP.NE4800 WIRING GUIDE

Version: 1.01

Last Updated: 11-04-2017



Notes:

NE4800 is the network enabled lift controller.

NE4800 work together with a POB board and a WIE.485 board can cater up to 32 floors. It can connect up to 16 POB boards which can cater maximum 512 floors.

NE4800 can connect up to 4 WIE.485 and each WIE.485 can connect 2 readers (Reader Type: Standard Wiegand).

It also support multi bit custom Wiegand format (Wiegand Group) for each reader. 4 key switch can be connected to POB board.

See <http://www.entrypass.net/> for updates, revisions, and download the latest installation manual

Platform1 version 3 support 6 and 10 digits format.

For existing site, P1 will detect its card database to determine 6 or 10 digits; For new site, user can change the digits as long as the card database is empty.

Please refer to separate EntryPass Platform1 User Manual for detail operation help. The Official EntryPass Platform1 User Manual can be downloaded from our website under "Download" section.



BEFORE YOU BEGIN

Technical Support

If you cannot find the answer to your question in this manual or in the Help files, we recommend you contact your system installer. Your installer is familiar with your system configuration and should be able to answer any of your questions.

Should you need additional information, please call our Technical Support Help desk, Monday to Friday 9:00 AM to 6:00 PM (GMT +8:00)

Method Details

Phone + 60 (3) - 8068 1929

Fax + 60 (3) - 8068 1922

Internet www.entrypass.net

Email support@entrypass.net



Considerations Prior to Installation

Preparing Your EntryPass Controllers

EntryPass controller contains numerous delicate electronic circuits and components which can become damaged as a result of electrostatic discharge (ESD). Thus, prior to installation, please follow the instruction below:

- Observe precautions while handling the circuit board assembly by using proper grounding straps and handling precautions at all
- Visually ensure no onboard parts is broken, damage or contains burn mark
- Do not turn on the power supply until you completed all wiring and external add on devices installations



CAUTION


Battery may explode if mistreated. Do not recharge, disassemble or dispose of in fire. To prevent a risk of explosion do not pry the battery out with a metal or conductive tool.

Instances of Non-Warranty


- Damage due to natural disaster, accident or human cause.
- Damage as a result of violating the conditions recommended in the user manual
- Damage due to improper installation
- Damage due to use of uncertified components
- Damage due to use exceeding the permitted parameters




NE4800 (HCB with ComGateway board)




ComGateway Component Description



Connecting the ComGateway board to NE4800



ComGateway Output Connector



POB Connector

- C4+ - POB 4 RS485 (+) Connection
- C4- - POB 4 RS485 (-) Connection
- C3+ - POB 3 RS485 (+) Connection
- C3- - POB 3 RS485 (-) Connection
- C2+ - POB 2 RS485 (+) Connection
- C2- - POB 2 RS485 (-) Connection
- C1+ - POB 1 RS485 (+) Connection
- C1- - POB 1 RS485 (-) Connection


WIE.485 Connector

- C4+ - WIE.485 4 RS485 (+) Connection
- C4- - WIE.485 4 RS485 (-) Connection
- C3+ - WIE.485 3 RS485 (+) Connection
- C3- - WIE.485 3 RS485 (-) Connection
- C2+ - WIE.485 2 RS485 (+) Connection
- C2- - WIE.485 2 RS485 (-) Connection
- C1+ - WIE.485 1 RS485 (+) Connection
- C1- - WIE.485 1 RS485 (-) Connection

Each POB RS485 connection can support Max. 4 unit POB controller



Legend Description




Power Supply Connector

- | | |
|----------|--------------------------------|
| +12V | - Power Supply Positive 12V DC |
| -12V/GND | - Power Supply Ground |
| ETH | - Power Supply Earthing |
| ACC | - AC Fail Monitoring |
| BAT/BS | - Backup Battery Monitoring |

BAT/BS (Backup Battery Monitoring) point will monitor the backup battery voltage which will supply power to the board when AC power is cut off
The minimum voltage for cutoff while using backup battery is 10V




Power Supply Unit Specification




- Power Supply Unit Specification:
- Switching Power Supply
 - 12V DC
 - 3 Amp (Minimum)



POB (Passive Output Board) Component Description



POB Digital Output Connector 1 (Upper)




Upper Connector

NC1 - Relay 1 Normally Close Connection
COM1 - Relay 1 Common Input
NO1 - Relay 1 Normally Open Connection
NC3 - Relay 3 Normally Close Connection
COM3 - Relay 3 Common Input
NO3 - Relay 3 Normally Open Connection
NC5 - Relay 5 Normally Close Connection
COM5 - Relay 5 Common Input
NO5 - Relay 5 Normally Open Connection
NC7 - Relay 7 Normally Close Connection
COM7 - Relay 7 Common Input
NO7 - Relay 7 Normally Open Connection

NC9 - Relay 9 Normally Close Connection
COM9 - Relay 9 Common Input
NO9 - Relay 9 Normally Open Connection
NC11 - Relay 11 Normally Close Connection
COM11 - Relay 11 Common Input
NO11 - Relay 11 Normally Open Connection
NC13 - Relay 13 Normally Close Connection
COM13 - Relay 13 Common Input
NO13 - Relay 13 Normally Open Connection
NC15 - Relay 15 Normally Close Connection
COM15 - Relay 15 Common Input
NO15 - Relay 15 Normally Open Connection
GND - Inputs Ground
IN2 - Input 2
IN1 - Input 1



POB Digital Output Connector 1 (Lower)




Lower Connector

- NC2 - Relay 2 Normally Close Connection
- COM2 - Relay 2 Common Input
- NO2 - Relay 2 Normally Open Connection
- NC4 - Relay 4 Normally Close Connection
- COM4 - Relay 4 Common Input
- NO4 - Relay 4 Normally Open Connection
- NC6 - Relay 6 Normally Close Connection
- COM6 - Relay 6 Common Input
- NO6 - Relay 6 Normally Open
- NC8 - Relay 8 Normally Close Connection
- COM8 - Relay 8 Common Input
- NO8 - Relay 8 Normally Open Connection

- NC10 - Relay 10 Normally Close Connection
- COM10 - Relay 10 Common Input
- NO10 - Relay 10 Normally Open Connection
- NC12 - Relay 12 Normally Close Connection
- COM12 - Relay 12 Common Input
- NO12 - Relay 12 Normally Open Connection
- NC14 - Relay 14 Normally Close Connection
- COM14 - Relay 14 Common Input
- NO14 - Relay 14 Normally Open Connection
- NC16 - Relay 16 Normally Close Connection
- COM16 - Relay 16 Common Input
- NO16 - Relay 16 Normally Open Connection
- GND - Inputs Ground
- IN4 - Input 4
- IN3 - Input 3



POB Digital Output Connector 2 (Upper)




Upper Connector

- NO17 - Relay 17 Normally Open Connection
- COM17 - Relay 17 Common Input
- NC17 - Relay 17 Normally Close Connection
- NO19 - Relay 19 Normally Open Connection
- COM19 - Relay 19 Common Input
- NC19 - Relay 19 Normally Close Connection
- NO21 - Relay 21 Normally Open Connection
- COM21 - Relay 21 Common Input
- NC21 - Relay 21 Normally Close Connection
- NO23 - Relay 23 Normally Open Connection
- COM23 - Relay 23 Common Input
- NC23 - Relay 23 Normally Close Connection

- NO25 - Relay 25 Normally Open Connection
- COM25 - Relay 25 Common Input
- NC25 - Relay 25 Normally Close Connection
- NO27 - Relay 27 Normally Open Connection
- COM27 - Relay 27 Common Input
- NC27 - Relay 27 Normally Close Connection
- NO29 - Relay 29 Normally Open Connection
- COM29 - Relay 29 Common Input
- NC29 - Relay 29 Normally Close Connection
- NO31 - Relay 31 Normally Open Connection
- COM31 - Relay 31 Common Input
- NC31 - Relay 31 Normally Close Connection



POB Digital Output Connector 2 (Lower)



Lower Connector


- NO18 - Relay 18 Normally Open Connection
- COM18 - Relay 18 Common Input
- NC18 - Relay 18 Normally Close Connection
- NO20 - Relay 20 Normally Open Connection
- COM20 - Relay 20 Common Input
- NC20 - Relay 20 Normally Close Connection
- NO22 - Relay 22 Normally Open Connection
- COM22 - Relay 22 Common Input
- NC22 - Relay 22 Normally Close Connection
- NO24 - Relay 24 Normally Open Connection
- COM24 - Relay 24 Common Input
- NC24 - Relay 24 Normally Close Connection

- NO26 - Relay 26 Normally Open Connection
- COM26 - Relay 26 Common Input
- NC26 - Relay 26 Normally Close Connection
- NO28 - Relay 28 Normally Open Connection
- COM28 - Relay 28 Common Input
- NC28 - Relay 28 Normally Close Connection
- NO30 - Relay 30 Normally Open Connection
- COM30 - Relay 30 Common Input
- NC30 - Relay 30 Normally Close Connection
- NO32 - Relay 32 Normally Open Connection
- COM32 - Relay 32 Common Input
- NC32 - Relay 32 Normally Close Connection



POB Power and Communication Connector


Power Supply Connection



Power Supply Connection

- +12V - Power Supply Positive 12V DC
- GND - Power Supply Ground
- ETH - Power Supply Earthing
- PG - AC Fail Monitoring
- BT.MON - Backup Battery Monitoring

RS485 Com Connection




RS485 Com Connection

- GND (485) - RS485 Ground
- C- - RS485 Com (-) Connection
- C+ - RS485 Com (+) Connection
- GND - (Not Applicable)
- CAN_H - (Not Applicable)
- CAN_L - (Not Applicable)

BT.MON (Backup Battery Monitoring) point will monitor the backup battery voltage which will supply power to the board when AC power is cut off
The minimum voltage for cutoff while using backup battery is 10V




Connecting the Keyswitch to POB controller



Keyswitch can only be connected IN1 , IN2 , IN3 and IN4 to GND





Connecting Power Supply to NE4800 and POB controller




POB Unit Address Dip Switch


If more than 1 POB controller is connected, the DIP switch must be configured according to the pattern shown below. The default DIP switch configuration of the POB controller is 1 (ON)




For POB Number 1



For POB Number 2



For POB Number 3



For POB Number 4



Connecting NE4800 and POB – DIP Switch Addressing


Unit Address	Switch 1	Switch 2	Switch 3	Switch 4	Switch 5	Switch 6	Switch 7	Switch 8
001	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
002	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
003	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF
004	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF

DIP Switch Addressing Table

Each switch is represent by an address, the sum of the switch address will be the controller address
The number in () is the address of each individual switch of the dip switch
Example: To obtain Address 11, $1 + 2 + 8 = 11$, So just switch on switch 1, 2, 4





Connecting POB to NE4800 controller




Note:

Each COM line can support only 4 POB controller. Loop C1+/- starting from POB1 if more than 1 POB controller is connected. It is advisable to connect a jumper at JP3 as terminator on last POB controller. Remove the jumper for the rest of POB.




Connecting 16 units POB controller (512 Floors)



WIE.485

120 Ohm Resistor




Note:


Is advisable connect 120 Ohm resistor on all WIE.485 board for RS485 signal termination.




Connecting the WIE.485 to NE4800 controller



Connecting WIE.485 and POB to NE4800 controller



Connecting the Reader to WIE.485





Put the jumper cap at JP5 1-2 to output 12VDC at Vout₁
Put the jumper cap at JP5 2-3 to output 5VDC at Vout₁

Put the jumper cap at JP6 1-2 to output 12VDC at Vout₂
Put the jumper cap at JP6 2-3 to output 5VDC at Vout₂



Connecting to the PC using TCP/IP mode



Default NE4800 controller network setting:


- 1) IP address: 192.168.1.100
- 2) Subnet Mask: 255.255.255.0
- 3) Gateway: 0.0.0.0
- 4) Server IP address: 192.168.1.254

To change the network setting, simply logon to the web server.

The distance from NE4800 controller to network switch should not more than 100 meter



Performing Cold Start




Steps of performing cold start:

1. Please ensure that the jumper is inserted on JP1 1-2
2. Press and Hold COLD
3. Press RESET Switch and Release RESET switch
4. Release COLD switches when a long beeping sound heard

Advisable to perform cold start for the first time you turn on the power
The buzzer will only beep if jumper is placed on JP2 1-2



Performing Factory Default



Make Sure the Jumper Cap is placed on JP1 (1-2) after factory default

Steps of performing Factory Default:

1. Please ensure that the jumper is inserted on JP1 7-8
2. Press and Hold COLD switch
3. Press RESET Switch and Release RESET switch
4. Release COLD switches when a long beeping sound heard

Factory Default will change the IP Address back to 192.168.1.100, Server IP to 192.168.1.254 and Port to 2020

For the network controller support AES Encryption feature, factory default will disable the AES feature

The buzzer will only beep if jumper is placed on JP2 1-2



Performing AES Hard Reset




Steps of performing AES Hard Reset:

1. Please ensure that the jumper is inserted on JP1 3-4
2. Press RESET Switch and Release RESET switch

AES setting in the controller will be reset
If the controller is connected with AES enabled Platform1, Platform1 will sync and update AES setting with the controller



Lift Application System Overview



Connecting to EntryPass Platform1 Access Control System

Before you begin to connect to the EntryPass Platform1 Access Control System, please make sure all the wiring connection is correct. On the NE4800, please make sure the following setting has been done:

Factory Default

Advisable to perform factory default for the first time you turn on the power

IP Address

To configure the EP.NE4800 controller IP address

Subnet Mask

To configure the EP.NE4800 controller subnet mask if required

Gateway

To configure the EP.NE4800 controller gateway if required

Server IP

To configure the EP.NE4800 controller Server IP to match the IP address of the Platform1 Server



Cabling Information

Communication	Data Signal	Max Distance	Description
NE4800 to PC or Switch	Network	100m (300 ft)	24 AWG, 4 Pairs (Cat 5e)
NE4800 to WIE.485	RS485	1000m (3000 ft)	22 AWG, 2 Pairs, Shielded & Twisted Pair
WIE.485 to Reader	Wiegand	30m (100 ft)	22 AWG, 2 Pairs, Shielded & Twisted Pair
NE4800 to POB	RS485	1000m (3000 ft)	22 AWG, 2 Pairs, Shielded & Twisted Pair
POB to Keyswitch	Contact	30m (100 ft)	22 AWG, 1 Pair

