



ENTRYPASS PLATFORM 1

MULTI-TENANCY MODULE

Entrypass P1 Multi-Tenancy (Cluster) is a module that is built into Entrypass Platform1 Server to cater for multi user environment with the capability of creating user specific sets of data which is attributable to that particular user only.



User Segregation & Decentralised System Management


User control and database is distinct from one cluster to another. Each clustered system will only be able to view data, perform system management and generate reports for their own clusters only. This will allow decentralised system management where clustered users will be able to manage and configure access control related settings without system administrators.



Personalised configuration

Despite Entrypass Platform1 Server is only a single system installed in a server, it has the capability to allow different clustered users to perform different settings while those settings are specific to their cluster.

P1 MULTI-TENANCY MODULE



Cluster Assignment

Everytime system administrators perform an activity of creating a new object (features & settings), the system will prompt the system administrator to assign which cluster that the new object should belong to, so as to enable the system to uniquely identify that object and all its subsequent transaction / data(s) with an identifier.

Feature Highlights:

Cluster specific data

When a cluster is created, all datas are cluster specific and attributable to that specific cluster.

Cluster specific controls

Within each cluster, clustered users will be able to perform configuration on objects like Access Group, Access Level, Department, Fire Release Group, Global Antipassback Group, Interlocking Group, Job, Map, Menu Control, Roll Call Group, Roster, Shift, Time Set and Time Zone.

Clustered Reporting

Clustered user will be able to generate report related to their own cluster.

Ordering Information

EP.P1.MT Entrypass P1 Multi-Tenancy Module License



www.entrypass.net

Malaysia

No. 40, Jalan TPP 1/10, Taman Industri Puchong, Batu 12 Jalan Puchong, 47160 Puchong Selangor Darul Ehsan, Malaysia.
Tel : +603 8068 1929
Fax : +603 8062 6937
Email : info@entrypass.net

Singapore

No. 1, UBI View, #03-03, Focus ONE Building, Singapore 408555.
Tel : +65- 6841 7242
Fax : +65- 6841 3937
Email : info@entrypass.net

Indonesia

Rukan Puri Mutiara Block BF No.17, Jln. Griya Utama, Sunter Agung, Jakarta Utara 14350, Indonesia
Tel : +62 21 2937 6098
Email : indonesia@entrypass.net